







LED STATUS AND BUTTON]

LED

 Red	Powered, not connected
 Blue flashing	In pairing mode
 Blue	Connected, music (A2DP)
 Green	Connected, speech (HFP/HSP)
 Green flashing	Incoming call
 Red flashing	Microphone muted

BUTTON

Press 3 sec	Activate pairing
Press 10 sec	Factory reset (clear all pairing)
Press short	Connect/disconnect



*Konftel is a Climate Neutral brand.
We offset all our greenhouse gas
emissions and are taking measures to
further reduce our emissions.*



900102141 Rev 1B

QUICK GUIDE

Konftel BT30



PHYSICAL CHARACTERISTICS]



FIRST TIME PAIRING: Activate pairing mode on the Konftel Bluetooth® speakerphone. Connect the BT30 to the USB port. BT30 will automatically pair with the speakerphone.

FOLLOWING PAIRING: Activate pairing mode on the Konftel Bluetooth® speakerphone. Press the button on the BT30 for 3 seconds until LED starts flashing blue. Pairing will be automatic.


USE CASES DESCRIPTION]

The Bluetooth® adapter enables wireless connection for wideband audio in two typical scenarios:



Connect a computer (PC or Mac) running your communication software of choice, to a Konftel Bluetooth® speakerphone.

i Once paired, select "Konftel BT30" as your audio device.



Connect to the Konftel OCC Hub and a Konftel Bluetooth® speakerphone, for video meetings with wireless HD audio.